

onset®

HOBOnode Wireless System

Quick Start Guide

www.onsetcomp.com

Follow the steps in this Quick Start Guide to setup a HOBOnode system. Steps 1-8 should be performed in a lab/office environment to familiarize yourself with the components and perform initial setup before you deploy the system in the field.

IMPORTANT: All HOBOnode devices come with rechargeable alkaline batteries, which **can only be purchased from Onset**. The HOBOnodes and HOBOnode Repeaters (but not the HOBOnode Receiver) can also use standard AAA lithium batteries, which can be purchased from Onset.


See the *HOBOnode Wireless System User Guide* at the following location for more details: <http://www.onsetcomp.com/support/manuals>

Components

The HOBOnode System includes:

- 1 HOBOnode Receiver (W-RCVR-USB)
- HOBOnode(s) (W-xxx)
- HOBOnode Repeater(s) (Optional) (W-REPEATER)

The following diagram shows an example deployment of a HOBOnode Wireless System.



Part# MAN-HOBOnode-QS Document # 12537-C

Step 1 - Download the HOBOnode Viewer utility

Download Onset's HOBOnode Viewer Utility software. You also must have Microsoft .NET version 3.5. HOBOnode Viewer and .NET can be downloaded from: http://www.onsetcomp.com/support/software_utilities

Step 2 - Run the HOBOnode Viewer Setup Wizard

Enter information in each window as required and click **Next** to proceed to the next window.

In the **General Information** pane, make sure you select your desired units.

In the **Alarm/E-mail Configuration** pane, enter the E-mail addresses for any accounts that you want to receive alarm notifications.

If you want to enable authentication, check the *use Authentication* box and enter a **Username** and **Password**.

If you are unsure of values for Server Address or Port, contact your IT Administrator or your Internet Service Provider (ISP).

NOTE: To skip this step, check the *skip and configure later ...* box and click **Next**.

Step 3 - Connect HOBOnode Receiver

Connect the HOBOnode Receiver to the PC. Put the Receiver into the base and mount vertically or lay horizontally on a desk. Make sure the antenna is pointing upward. The Receiver will automatically connect to HOBOnode Viewer within approximately 1 to 2 minutes and an icon will appear in the Network Tree. Only one HOBOnode Receiver can be connected to a single PC.

Step 4 - Set HOBOnode System Network ID

Before you activate HOBOnodes, you must set the HOBOnode Network ID for the HOBOnode Receiver to make your HOBOnode Network unique from any other HOBOnode or wireless networks that may be in the area.

If you are setting up more than one HOBOnode network, use unique RF Channels for each.

NOTE: This is for your HOBOnode network only and is not related to your corporate network or any other wireless or internet network.


- Right-click on the Receiver icon and select **Send Command > Set Network ID**
- Select a unique **RF Channel** (11-25) and **Unique ID** (0-4095).



Step 5 - Activate Devices (If not already Activated)


You must push the **Set/Clear** button on HOBOnodes and Repeaters to activate them. Remove the cap and locate the brown button. Hold it down for 2 seconds. The LEDs will flash briefly to indicate that the device is activated.

Activating HOBOnodes



Activating Repeaters

See the *HOBOnode Repeater Setup Guide* for details on setting up and deploying the HOBOnode Receiver.



Step 6 - Link Devices to the HOBOnode Receiver

In HOBOnode Viewer, right-click on the Receiver icon and select **Send Command > Start Manual Search**. The Receiver will search for any HOBOnodes or HOBOnode Repeaters within its range. As nodes are linked to the Receiver, they will appear in the Network Tree.

Step 7 - Add Labels to Nodes (Optional)

In HOBOnode Viewer, right-click on a node icon, select **Set Label**, and enter a label for the node.

Step 8 - Configure Alarms (Optional)

In HOBOnode Viewer, right-click on a node icon, select **Configure Alarms**, and enter values for the alarm.

Step 9 - Deploy HOBOnodes

Deploy HOBOnodes in desired locations. Attach the mounting bracket to a wall, post, or tree, then insert the HOBOnode into the bracket. Make sure the cable is hanging down and has a drip-loop.

Step 10 - Deploy HOBOnode Repeaters (if required)

Onset recommends you mount HOBOnode Repeaters and antennas to an Onset tri-pod, however, you can mount them to a pole. The Directional antenna connects the HOBOnode Repeater to the HOBOnode Receiver and should be pointing as directly at the HOBOnode Receiver as possible to optimize the connection.

Refer to the *HOBOnode Repeater Setup Guide* for more information.

Step 11 - Re-link Devices

When all nodes are deployed, go to HOBOnode Viewer and perform an Auto Search. Verify that all nodes are linked to the correct HOBOnode Receiver or Repeater.

Troubleshooting

- If you are having trouble linking a component to the receiver or repeater, try repositioning the component.
- If you experience general connection problems, try assigning a different RF Channel to the HOBOnode Receiver, and then reset all of the devices so that they re-link to the Receiver with the new Network ID. See the *HOBOnode Wireless System User Guide* for information on resetting nodes.

FCC Compliance

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by Onset Computer Corporation could void the user's authority to operate the equipment.

To comply with FCC and Industry Canada RF radiation exposure limits for general population, the HOBOnode Receiver and the HOBOnode Repeaters must be installed to provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

Canada

This device has been designed to operate with the antennas listed below, and having a maximum gain of 15 dB. Antennas not included in this list or having a gain greater than 15 dB are strictly prohibited for use with this device. The required antenna impedance is 50 ohms.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that permitted for successful communication.

FCC Declaration of Conformity

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Maximum Allowed Antenna Gain

Part	Max Gain
W-RCVR-USB	5 dBi
W-REPEATER	Local Antenna (Omni-Directional): 5 dBi
	Long Distance Antenna (Directional): 15 dBi